



2010 FORTE



KIA MOTORS
The Power to Surprise™

Maintenance Schedule

- **Model:** FORTE/FORTE KOUP(TD) / 2010
- **Trans:** M/T
- **Drive:** ALL

• Vehicle Maintenance Requirements

The following maintenance services must be performed to help ensure safe, dependable operation and performance. Retaining all maintenance / service documents and receipts will help establish your compliance with your vehicle's warranty requirements. Maintenance frequency is determined by mileage or time, whichever comes first. Please refer to your Owner's Manual and the Warranty and Consumer Information Manual for further details.

Mileage/Month	Replace Maintenance Items	Inspection Maintenance Items
7,500 miles / 6 months	<ul style="list-style-type: none"> • Engine oil and filter • Rotate tires (including tire pressure and tread wear) 	<ul style="list-style-type: none"> • Air cleaner element • Cooling system Note 2 • Brake/clutch fluid • Brake lines, hoses and connections • Brake pedal and operation • Battery condition • Chassis/body nuts and bolts • Drum brakes and linings* • Disc brakes and pads • Exhaust pipe and muffler • Front suspension ball joints • Lubricate all locks and hinges • Power steering pump, belts and hoses • Parking brake • Steering operation and linkage • Suspension mounting bolts • Vacuum Hoses • Air conditioner compressor / refrigerant / performance*
15,000 miles / 12 months	<ul style="list-style-type: none"> • Engine oil and filter • Rotate tires (including tire pressure and tread wear) 	
22,500 miles / 18 months	<ul style="list-style-type: none"> • Engine oil and filter • Rotate tires (including tire pressure and tread wear) • Climate control air filter* 	<ul style="list-style-type: none"> • Air cleaner element • Cooling system Note 2 • Drive shaft and boots - Lubricate front and rear driveshaft u-joint • Brake/clutch fluid • Brake lines, hoses and connections • Brake pedal and operation • Battery condition • Chassis/body nuts and bolts • Drum brakes and linings* • Disc brakes and pads • Exhaust pipe and muffler • Front suspension ball joints • Lubricate all locks and hinges • Power steering pump, belts and hoses • Parking brake • Steering operation and linkage • Suspension mounting bolts • Vacuum Hoses • Air conditioner compressor / refrigerant / performance*
30,000 miles / 24 months	<ul style="list-style-type: none"> • Engine oil and filter • Air cleaner element • Rotate tires (including tire pressure and tread wear) • Climate control air filter* 	<ul style="list-style-type: none"> • Fuel filter Note 1 • Fuel tank cap, lines and hoses • Fuel tank air filter (CCV filter) • Manual transaxle fluid (LEVEL AND CONDITION) • Cooling system Note 2 • Brake/clutch fluid • Brake lines, hoses and connections • Brake pedal and operation • Battery condition • Chassis/body nuts and bolts • Drum brakes and linings* • Disc brakes and pads • Exhaust pipe and muffler • Front suspension ball joints • Lubricate all locks and hinges • Power steering pump, belts and hoses • Parking brake • Steering operation and linkage • Suspension mounting bolts • Vacuum Hoses • Air conditioner compressor / refrigerant / performance*
37,500 miles / 30 months	<ul style="list-style-type: none"> • Engine oil and filter • Rotate tires (including tire pressure and tread wear) 	
40,000 miles / 48 months		
45,000 miles / 36 months	<ul style="list-style-type: none"> • Engine oil and filter • Rotate tires (including tire pressure and tread wear) • Climate control air filter* 	<ul style="list-style-type: none"> • Air cleaner element • Cooling system Note 2 • Drive shaft and boots - Lubricate front and rear driveshaft u-joint • Brake/clutch fluid • Brake lines, hoses and connections • Brake pedal and operation • Battery condition • Chassis/body nuts and bolts • Drum brakes and linings* • Disc brakes and pads • Exhaust pipe and muffler • Front suspension ball joints • Lubricate all locks and hinges • Power steering pump, belts and hoses

		<ul style="list-style-type: none"> ● Parking brake ● Steering operation and linkage ● Suspension mounting bolts ● Vacuum Hoses ● Air conditioner compressor / refrigerant / performance*
52,500 miles / 42 months	<ul style="list-style-type: none"> ● Engine oil and filter ● Rotate tires (including tire pressure and tread wear) 	
60,000 miles / 48 months	<ul style="list-style-type: none"> ● Engine oil and filter ● Engine coolant ● Air cleaner element ● Rotate tires (including tire pressure and tread wear) ● Climate control air filter* 	<ul style="list-style-type: none"> ● Fuel filter Note 1 ● Fuel tank cap, lines and hoses ● Fuel tank air filter (CCV filter) ● Valve clearance ● Manual transaxle fluid (LEVEL AND CONDITION) ● Cooling system Note 2 ● Brake/clutch fluid ● Brake lines, hoses and connections ● Brake pedal and operation ● Battery condition ● Chassis/body nuts and bolts ● Drum brakes and linings* ● Disc brakes and pads ● Exhaust pipe and muffler ● Front suspension ball joints ● Lubricate all locks and hinges ● Power steering pump, belts and hoses ● Parking brake ● Steering operation and linkage ● Suspension mounting bolts ● Vacuum Hoses ● Air conditioner compressor / refrigerant / performance*
67,500 miles / 54 months	<ul style="list-style-type: none"> ● Engine oil and filter ● Rotate tires (including tire pressure and tread wear) 	
75,000 miles / 60 months	<ul style="list-style-type: none"> ● Engine oil and filter ● Rotate tires (including tire pressure and tread wear) ● Climate control air filter* 	<ul style="list-style-type: none"> ● Air cleaner element ● Cooling system Note 2 ● Drive shaft and boots - Lubricate front and rear driveshaft u-joint ● Brake/clutch fluid ● Brake lines, hoses and connections ● Brake pedal and operation ● Battery condition ● Chassis/body nuts and bolts ● Drum brakes and linings* ● Disc brakes and pads ● Exhaust pipe and muffler ● Front suspension ball joints ● Lubricate all locks and hinges ● Power steering pump, belts and hoses ● Parking brake ● Steering operation and linkage ● Suspension mounting bolts ● Vacuum Hoses ● Air conditioner compressor / refrigerant / performance*
80,000 miles / 96 months		
82,500 miles / 66 months	<ul style="list-style-type: none"> ● Engine oil and filter ● Rotate tires (including tire pressure and tread wear) 	
90,000 miles / 72 months	<ul style="list-style-type: none"> ● Engine oil and filter ● Engine coolant ● Air cleaner element ● Rotate tires (including tire pressure and tread wear) ● Climate control air filter* 	<ul style="list-style-type: none"> ● Fuel filter Note 1 ● Fuel tank cap, lines and hoses ● Fuel tank air filter (CCV filter) ● Manual transaxle fluid (LEVEL AND CONDITION) ● Cooling system Note 2 ● Drive belts Note 3 ● Brake/clutch fluid ● Brake lines, hoses and connections ● Brake pedal and operation ● Battery condition ● Chassis/body nuts and bolts ● Drum brakes and linings* ● Disc brakes and pads ● Exhaust pipe and muffler ● Front suspension ball joints ● Lubricate all locks and hinges ● Power steering pump, belts and hoses ● Parking brake ● Steering operation and linkage ● Suspension mounting bolts ● Vacuum Hoses ● Air conditioner compressor / refrigerant / performance*
97,500 miles / 78 months	<ul style="list-style-type: none"> ● Engine oil and filter ● Rotate tires (including tire pressure and tread wear) 	
105,000 miles / 84 months	<ul style="list-style-type: none"> ● Engine oil and filter ● Spark plugs ● Rotate tires (including tire pressure and tread wear) ● Climate control air filter* 	<ul style="list-style-type: none"> ● Air cleaner element ● Cooling system Note 2 ● Drive shaft and boots - Lubricate front and rear driveshaft u-joint ● Brake/clutch fluid ● Brake lines, hoses and connections ● Brake pedal and operation ● Battery condition ● Chassis/body nuts and bolts ● Drum brakes and linings* ● Disc brakes and pads ● Exhaust pipe and muffler ● Front suspension ball joints ● Lubricate all locks and hinges ● Power steering pump, belts and hoses ● Parking brake ● Steering operation and linkage ● Suspension mounting bolts ● Vacuum Hoses ● Air conditioner compressor / refrigerant / performance*

112,500 miles / 90 months	<ul style="list-style-type: none"> Engine oil and filter Rotate tires (including tire pressure and tread wear) 	
120,000 miles / 96 months	<ul style="list-style-type: none"> Engine oil and filter Engine coolant Air cleaner element Rotate tires (including tire pressure and tread wear) Climate control air filter* 	<ul style="list-style-type: none"> Fuel filter Note 1 Fuel tank cap, lines and hoses Fuel tank air filter (CCV filter) Valve clearance Manual transaxle fluid (LEVEL AND CONDITION) Cooling system Note 2 Drive belts Note 3 Brake/clutch fluid Brake lines, hoses and connections Brake pedal and operation Battery condition Chassis/body nuts and bolts Drum brakes and linings* Disc brakes and pads Exhaust pipe and muffler Front suspension ball joints Lubricate all locks and hinges Power steering pump, belts and hoses Parking brake Steering operation and linkage Suspension mounting bolts Vacuum Hoses Air conditioner compressor / refrigerant / performance*
127,500 miles / 102 months	<ul style="list-style-type: none"> Engine oil and filter Rotate tires (including tire pressure and tread wear) 	
135,000 miles / 108 months	<ul style="list-style-type: none"> Engine oil and filter Rotate tires (including tire pressure and tread wear) Climate control air filter* 	<ul style="list-style-type: none"> Air cleaner element Cooling system Note 2 Drive shaft and boots - Lubricate front and rear driveshaft u-joint Brake/clutch fluid Brake lines, hoses and connections Brake pedal and operation Battery condition Chassis/body nuts and bolts Drum brakes and linings* Disc brakes and pads Exhaust pipe and muffler Front suspension ball joints Lubricate all locks and hinges Power steering pump, belts and hoses Parking brake Steering operation and linkage Suspension mounting bolts Vacuum Hoses Air conditioner compressor / refrigerant / performance*
142,500 miles / 114 months	<ul style="list-style-type: none"> Engine oil and filter Rotate tires (including tire pressure and tread wear) 	
150,000 miles / 120 months	<ul style="list-style-type: none"> Engine oil and filter Engine coolant Air cleaner element Rotate tires (including tire pressure and tread wear) Climate control air filter* 	<ul style="list-style-type: none"> Fuel filter Note 1 Fuel tank cap, lines and hoses Fuel tank air filter (CCV filter) Manual transaxle fluid (LEVEL AND CONDITION) Cooling system Note 2 Drive belts Note 3 Brake/clutch fluid Brake lines, hoses and connections Brake pedal and operation Battery condition Chassis/body nuts and bolts Drum brakes and linings* Disc brakes and pads Exhaust pipe and muffler Front suspension ball joints Lubricate all locks and hinges Power steering pump, belts and hoses Parking brake Steering operation and linkage Suspension mounting bolts Vacuum Hoses Air conditioner compressor / refrigerant / performance*

Notes

* if equipped

[Note 1](#) The fuel filter is considered to be a maintenance free but periodic inspection is recommended for this maintenance schedule depends on fuel quality. If there are some important safety matters like fuel flow restriction, surging, loss of power, hard start problem etc, replace the fuel filter immediately regardless of maintenance schedule and consult an authorized KIA dealer for details.

[Note 2](#) Inspect "Water Pump" when replacing the drive belt.

[Note 3](#) The drive belt should be replaced when cracks occur or tension is reduced excessively.